


























# LEC Start Up Procedure

- 1** Dry cycle mold, apply full tonnage, 3–4 times (pinch any wires in advance of operation)
- 2** Turn “On” main disconnect
- 3** Select  automatic set point   
Select Zone 1 , Zone 2  or “both”    
Enter automatic set point  . Press enter   
Repeat for other zones or modules
- 4** Select  automatic/manual mode   
Select Zone 1 , Zone 2  or “both”    
Enter “0” for automatic  . Press enter   
Repeat for other zones or modules
- 5** Select Zone 1 , Zone 2  or “both”    
Press “Up”  and “Select”  together (Power “On”)   
Apply power to manifolds first if required by manifold supplier  
Repeat for other zones or modules
- 6** Zones will read a low temperature alarm  
Zones are close or holding set point when the green temperature holding set point light is illuminated





























Sterling, VA USA Tel. +1-(703) 471-5050  
 Wiesbaden, Germany Tel. +49-(0)-611-973430  
 Ube, Japan Tel. +81-(836) 54-4369  
 Singapore Tel. +65-901-83710  
 www.gammaflux.com; www.gammaflux.de








# LEC

## Temperature Controller







### Basic Operation / Advanced Setup / Troubleshooting

	Thermocouple Open
	Thermocouple Pinched
	Thermocouple Reversed
	Degrees C
	Type K Thermocouple
	Uncontrolled Output
	Open Fuse
	Shorted Heater
	Open Heater
	Alarm Status
	Actual Temperature
	Actual % Output
	Actual Current (Amps)
	Automatic/Manual Mode
	Manual % Output Set Point
	Automatic Set Point
	Select
	Enter
	Increment (Up)
	Decrement (Down)
	Power “On”
	Power “Off”
	Standby
	Boost
	First Zone (Zone 1)
	Second Zone (Zone 2)


  

Display	
Actual Row	
Setting Row	
Entry Area	
Zone Select	
Zone Status	
Zone ID	

	Zone selected
	Alarm
	High Alarm
	Zone “On”
	Low Alarm
	Manual Mode

# How to Enter a Set Point



## Enter Automatic Temperature Set Point

- 1 Select zone(s) 1, 2 or 1 2
- 2 Select automatic set point
- 3 Enter temperature set point
- 4 Press enter to confirm

Automatic set point

Press "Up" or "Down" to adjust temperature  
(Press "Up" and "Down" together to change individual digits - 100, 10 or 1)

Select

Enter

Zone select indication  
(Press "1" and "2" together to select "both")

Tip 1

Tip 2

# How to Select Automatic or Manual

- 1 Select zone(s) 1, 2 or 1 2
- 2 Select automatic/manual mode
- 3 Enter "0" for automatic or closed loop control  
Enter "1" for manual or open loop control
- 4 Press enter to confirm



Automatic/Manual mode

Select

Enter

Zone select

Manual mode light  
(No light = automatic mode)

# How to Turn the Power "On" & "Off"

## Turn zone(s) "On"

- 1 Select zone(s) 1, 2 or 1 2
- 2 Press "Up" and "Select" together to turn power "On"

Manual % output set point

Select

Enter


Zone select

Tip 3

Tip 4

## Enter Manual % Output Set Point

- 1 Select zone(s) 1, 2 or 1 2
- 2 Select manual % output set point
- 3 Enter manual % set point (0 - 99.9%)
- 4 Press enter to confirm



Zone(s) "On"

Zone(s) "Off"

Press "1", "2", or "1 & 2" together to select "both"

Tip 1

Tip 2

## Turn zone(s) "Off"


- 1 Select zone(s) 1, 2 or 1 2
- 2 Press "Down" and "Enter" together to turn power "Off"

# Standard Controller Enclosure Wiring

# Optional Network Module Wiring

All Wiring Diagrams Represent Actual Connectors on Back Panels of LEC Controllers

## 6 & 12 Zone Enclosures



### Power

- Female insert on enclosure
- Dual latch


### Thermocouple

- Male insert on enclosure
- Dual latch

## HA4 Input/Output Connector

### Standby input


- 24 or 120 VAC/VDC input to activate
- All zones go to standby mode
- If standby set point is "1", module will be inhibited
- Configure in Advanced Setup
- Male insert on enclosure



### Alarm output

- 22 – 265 VAC/VDC must be supplied
- Normally open contact
- Contact is closed when any zone is in alarm for 16 seconds
- Fused at 5 amps

## 2 Zone Enclosure




### Combination Power and Thermocouple

- Female insert on enclosure
- Dual latch

## Remote Computer & Enclosure Link Connections

- Female DB25 enclosure link connector on network module enclosure
- Male DB25 enclosure link connector on stacked enclosure
- Connect two enclosures to one network module
- Share input, output and communications




- Female DB9 remote computer connector on enclosure
- Complimentary monitoring software including Gammavision, Mold Monitor, Mold Doctor and Field Calibrator



Sterling, VA USA Tel. +1-(703) 471-5050  
 Wiesbaden, Germany Tel. +49-(0)-611-973430  
 Ube, Japan Tel. +81-(836) 54-4369  
 Singapore Tel. +65-901-83710  
 www.gammaflux.com; www.gammaflux.de

The LEC controller is shipped to the customer so that no setup work is required for basic operation. Set points in automatic and manual may be entered and the zone will be controlled by turning "On" the power. Many customers require advanced features to satisfy their operation. This page will describe the basics of "Advanced Setup". Please note that security level codes are not standard. To place security on the LEC controller you must activate security by selecting your own personalized security codes (network module required).



## Advanced Setup Guide - Level 2 Security to Change

#	Limit (default)	Explanation	Set individually by zone
(0)	0 - 4 (0)	Power Priority™. 0 = (off). 1 - 4 = increased smoothing of power output. A = Power Priority™ is active (setup number)	
(1)	0-999 (0)	* Reset advanced setup to default values - enter 321; press enter to confirm	
(2)	0-100° F/55° C (20° F/11° C)	Temperature deviation alarm set point (individual) Actual temperature activates individual zone alarm at this amount +/- set point	
(3)	-31 to 27 (0)	Control algorithm adjustment (individual). 0=auto selection. To view actual tuning value select code 4 Manual Selections: 10 to 17 fast tuning with increasing lag. 20 to 27 slow tuning with increasing lag -17 to -10 fast manifold tuning with increasing lag. -27 to -20 very fast tuning with increasing lag -30 and -31 ultra fast low mass tuning. P = auto selection tune performed (setup number)	
(4)	-31 to 27 (none)	Algorithm set point (view only). View auto tuning selection or manual tuning value	
(5)	0-932° F/500° C (220° F/104° C)	Standby set point (individual). When standby is activated, all automatic zones selected will control to this set point Entering "1" will inhibit the module (both zones), when activated the relays will open, turning "off" the module power	
(6)	0 to 54.0 minutes (5.0)	T/C pinched detection time (individual) 98+% output, 20° F/11° C in 5 minutes - default. Change alarm timer amount. 0 = disabled	
(7)	32-999° F/0-537° C (779° F/415° C)	* Critical over temperature alarm. To clear the alarm, select alarm status and press enter If this temperature is exceeded for 8 seconds both zones turn "Off". Max. 999° F (537° C) = disabled	
(8)	32-932° F/0-500° C (752° F/400° C)	* Automatic set point limit. The maximum set point an operator can enter in automatic on both zones	
(9)	0-99.9% (99.9%)	* Manual set point limit. The maximum set point an operator can enter in manual on both zones	
(10)	0-999° F/537° C (100° F/55° C)	* Boost limit. The maximum amount of degrees an operator can raise or lower the zone(s) during a boost	
(11)	+/-99° F/55° C (36° F/20° C)	* Initial boost set point. Amount of degrees added to automatic set point, module adjustable within the boost limit	
(12)	0-999 seconds (120)	* Boost time set point. The amount of time boost is active	
(13)	0 or 1 (0)	* Degree F or C selection. 0="degree F"; 1="degree C"	
(14)	0 or 1 (0)	* Type J or K thermocouple selection. 0="type J"; 1="type K"	
(15)	0 or 1 (0)	* Zone power status on power up. 0 = all zones turned "Off"; 1 = zones "On" when shut down last, stay "On"	
†(16)	0 or 1 (0)	* Enable slaved power-up. 0="Off"; 1="On". All zones heat within 20° F/11° C of one another until set point	
†(17)	0-999 (none)	* Security code level 1. You must be in level 2 to change. Refresh procedure available, call Gammaflux	
†(18)	0-999 (none)	* Security code level 2. You must be in level 2 to change. Refresh procedure available, call Gammaflux	
(19)	- - -	Output module controller software version/revision number (display only), select zone, version/revision displayed	
(20)	- - -	Temperature controller software version/revision number (display only), select zone, version/revision displayed	
(21)	0 (0)	LED test. To activate enter 0. Turns "On" all LED's for troubleshooting	
†(22)	000-999 (level 2)	Security level indicated. 0=lockout; 1=operator; 2=supervisor. 0 - enter, drops one level Elevate one security level at a time with your customized code	

† Network module required

\* Network module distribution or value applies to both zones on the module

## Why Standby? How to Activate

Some processors like to maintain a lower set point on command for all zones while they are working on something.

Select zone(s) to put into standby **1**, **2** or **1 2**

Press "down" and "select" together

The selected zone(s) will go to the standby temperature

Hotter zones will cool to the standby temperature

Colder zones will heat to the standby temperature


Automatic zones = 220° F/104° C (default)

Manual zones = half of the manual set point

The outer decimal points will flash during standby

To cancel standby, press "down" and "select" together


The original standby source must be cancelled to clear standby. Please reference alternate standby inputs, shown to the right



## Alternate Standby Inputs



Standby switch on enclosure (if available) all zones go to standby mode



- 24 or 120 VAC/VDC input to activate
- All zones go to standby mode (network module required)



- Standby button from external software
- Selected zone(s) go to standby mode (network module required)

## Why Boost? How to Boost

Boost temporarily raises a zone(s) temperature (typically tips) to clear a cold slug on start up.


Select zone(s) to boost **1**, **2** or **1 2**

Press "up" and "enter" together  
Enter boost amount . Press enter

Zone(s) will boost 36°F/20°C (default) for 120 seconds (default)

The 7 segment display will flash during boost

To cancel boost, press "up" and "enter" together



## How to View All Zones Quickly

**1** Tip 1 - in alarm, select zone **1**

Select alarm status

**2** Tip 2 - normal operation

Zone is on, in automatic and at or near set point


**3** Tip 3 - in manual,

Thermocouple may be open  
Module applying a constant % output to the heater

**4** Tip 4 - in automatic,  
High temperature alarm  
(+20° F/11° C default)

**5** Man 1 - normal operation

**6** Sprue - low alarm



# Basic Troubleshooting


**Thermocouple pinched** - The T/C is pinched or the controller thinks it is pinched. (Default: 98+ % output, must see +20° F/11° C in 5 minutes). True pinch - the T/C is sensing the temperature further away from the heat source than intended. Without alarm, temperature reads low, controller applies power, runaway heat. False T/C pinch - heater is too small to heat the zone or the T/C is located too far away. Replace heater, move T/C or adjust alarm. Selectable detection times in advanced setup

**Thermocouple (T/C) open** - the T/C connection is broken, follow general troubleshooting

**Open heater** - The heater connection is broken, follow general troubleshooting

**Shorted heater** - The heater is shorted or exceeds the maximum rating of the module, follow general troubleshooting

**Open fuse** - fuse on module bad. Turn "Off" main disconnect. Remove top cover, locate module, check all fuses (4 per module, 2 per zone)



**Thermocouple reversed** - The T/C connection is wired + to - at some point. Visually inspect each connection, for type J (US standard) red wire should connect to red wires, not red to white

**Critical over temperature** - The temperature of a zone exceeded the alarm limit. (Default: 779°F/415° C). Both zones on the module shut "off" automatically. To clear the alarm, select alarm status and press enter. Noted by vertical indicator segment

**Uncontrolled output** - The module has an unregulated output. Both zones on the module shut "off" automatically. To clear the alarm, select alarm status and press enter. Noted by vertical and horizontal indicator segment (shown)

**Over-Voltage** - The module line voltage exceeded 280 VAC for 1 minute (informational only)

## General Troubleshooting - Turn "Off" Main Disconnect


- 1** Check resistance from pin to pin, at the mold. T/C should read 3-50 ohms at room temperature. Heater should read greater than 16 ohms. If there is no continuity (open line) = broken connection, open heater or open T/C.
- 2** Check resistance from pin to ground, at the mold. Heaters only - no continuity (open line) = good. Some resistance is bad, heater shorted.
- 3** Reattach the cable to the mold, detach the cable from the controller. Check resistance from pin to pin on the cable. T/C should read 3-50 ohms at room temperature. Heater should read greater than 16 ohms. If there is no continuity (open line) = broken connection, open heater or open T/C. The connection is broken in the cable set or the connectors/pins are not making contact.
- 4** Reattach the cable to the mold, detach the cable from the controller. Check resistance from pin to ground on the cable. Heaters only - no continuity (open line) = good. Some resistance is bad, heater shorted. The wires are either shorted in the cable set or the connectors are shorted to ground.
- 5** At this point if everything is fine, the problem is in the controller. (1) turn "Off" main disconnect, (2) locate problem module, (3) check fuses on module, (4) swap bad module into a known good location, (5) turn "On" main disconnect, (6) test the zone. If the problem follows the module = bad module. If the alarm stays with the original zone, the problem is between the module and the connectors on the rear of the enclosure.

- 6** If the problem is not explained, or you need spare parts please contact:

Gammaflux USA +1-(703) 471-5050  
info@gammaflux.com; www.gammaflux.com

Gammaflux Europe +49-(0)-611-973430  
info@gammaflux.de; www.gammaflux.de

Gammaflux Asia-Pacific  
Japan Tel. +81-(836) 54-4369  
Singapore Tel. +65-901-83710  
gammafluxjpn@gammaflux.com



- |   |   |
|---|---|
| <b>1</b> Output module  | <b>7</b> Power output connector                 |
| <b>2</b> Module thermocouple/communications cable             | <b>8</b> Auxiliary input/output connector       |
| <b>3</b> Module power input/output connector (base of module) | <b>9</b> Enclosure link connector               |
| <b>4</b> Input power cable                                    | <b>10</b> Communications port                   |
| <b>5</b> Main disconnect (circuit breaker)                    | <b>11</b> Ground stud                           |
| <b>6</b> Thermocouple input connector                         | <b>12</b> Fan                                   |
|   | <b>13</b> System wide standby switch (on front) |
|   | <b>14</b> Capacitors                            |